



RIFTEK

Sensors & Instruments



LASER SEAM TRACKING SYSTEM FOR WELDING AUTOMATION

RF627Weld Series

User's manual

22, Logoisky tract, Minsk
220090, Republic of Belarus
tel/fax: +375 17 357 36 57
info@riftek.com
www.riftek.com

Contents

1.	Safety precautions	4
2.	CE compliance	4
3.	Laser safety	4
4.	General information	4
5.	Structure	4
5.1.	Laser scanner	5
5.2.	Riftek Lamia software	5
5.3.	Controller	5
5.4.	Cables	6
5.4.1.	UNITRONIC® LiYCY (TP) cable	6
5.4.2.	RJ-45 Ethernet cable	7
5.4.3.	Power cable	7
5.5.	Calibration plate	7
6.	Operating principle	7
7.	Basic technical data	8
7.1.	Laser scanner	8
7.1.1.	Specification	8
7.1.2.	Working ranges and overall dimensions	8
7.2.	Controller	10
7.2.1.	Specification	10
7.2.2.	Overall dimensions	11
8.	Example of item designation when ordering	11
9.	Overall demands for mounting	11
10.	Ethernet interface	12
11.	Network configuration	12
12.	Connection procedure	13
13.	Setting parameters of the scanner. Web page	13
14.	Riftek Lamia software	15
14.1.	System requirements	15
14.2.	Installation	15
14.3.	User's interface description	16
14.3.1.	Main window	16
14.3.2.	"Settings" window	17
14.3.3.	"Tools" window	18
14.3.4.	"About" window	19
14.3.5.	Keyboard shortcuts	19
14.4.	Search for scanners	20
14.5.	Connection	21
14.6.	Selecting a template for seam tracking. "MATHS" panel	22
14.6.1.	General information	22
14.6.2.	Search parameters ("SEARCH" tab)	23
14.6.3.	Template parameters ("TEMPLATE" tab)	25
14.6.4.	List of measurements ("SELECT" tab)	26
14.6.5.	Built-in templates	28
14.6.5.1.	Template 1 "Fillet weld"	29
14.6.5.2.	Template 2 "Corner weld"	30
14.6.5.3.	Template 3 "Lap weld"	31
14.6.5.4.	Template 4 "Square-groove butt weld"	32
14.6.5.5.	Template 5 "V-groove weld"	33
14.6.5.6.	Template 6 "Left edge"	34
14.6.5.7.	Template 7 "Right edge"	35
14.6.5.8.	Template 8 "Spot weld"	36
14.6.5.9.	Template 9 "Nearest point"	37
14.6.5.10.	Template 10 "Slope"	38
14.6.6.	Operations with templates	39

14.6.6.1.	Adding a template.....	39
14.6.6.2.	Copying a template.....	39
14.6.6.3.	Removing a template.....	39
14.6.6.4.	Changing the order.....	40
14.6.6.5.	Restoring a default set of templates.....	40
14.7.	Working with welding robots. "PROTOCOLS" panel.....	40
14.7.1.	General information.....	40
14.7.2.	Functional diagram.....	40
14.7.3.	Connection procedure.....	41
14.7.4.	R691 USI protocol.....	41
14.7.4.1.	General information.....	41
14.7.4.2.	Client (robot) requests.....	42
14.7.4.3.	Scanner answers.....	43
14.7.4.4.	Error codes.....	43
14.7.4.5.	Scanner status.....	43
14.7.4.6.	Example	44
14.7.5.	Riftek P2 protocol.....	44
14.7.5.1.	General information.....	44
14.7.5.2.	Holding registers.....	45
14.7.5.3.	Operation logic.....	46
14.7.6.	EtherNet/IP protocol.....	46
14.7.6.1.	General information.....	46
14.7.6.2.	Explicit messaging.....	47
14.7.6.2.1.	Identity object (class 0x01).....	47
14.7.6.2.2.	TCP/IP object (class 0xF5).....	47
14.7.6.2.3.	Ethernet link object (class 0xF6).....	48
14.7.6.3.	Implicit messaging.....	48
14.7.6.3.1.	Assembly object (class 0x04).....	48
14.7.6.3.2.	Input assembly (instance 0x65).....	48
14.7.6.3.3.	Output assembly (instance 0x66).....	49
14.7.6.3.4.	Configuration assembly (instance 0x64).....	50
14.7.7.	Scanner calibration.....	50
14.7.7.1.	"Calibration" panel.....	50
14.7.7.2.	Calibration procedure.....	51
15.	Maintenance.....	52
16.	Troubleshooting.....	53
17.	Warranty policy.....	53
18.	Technical support.....	53
19.	Revisions.....	53
20.	Distributors.....	54

1. Safety precautions

- Use supply voltage and interfaces indicated in the scanner and controller specifications.
- When connecting / disconnecting cables, the power of the scanner and controller must be turned off.
- To obtain stable results, wait about 20 minutes after scanner activation to achieve uniform scanner warm-up.
- The scanner and controller must be grounded.

2. CE compliance


The system has been developed for use in industry and meets the requirements of the following Directives:

- EU directive 2014/30/EU. Electromagnetic compatibility (EMC).
- EU directive 2011/65/EU, “RoHS” category 9.

3. Laser safety

Scanners belong to 2M laser safety class according to IEC/EN 60825-1:2014.

Scanners make use of an c.w. 660 nm or 405 nm or 450 nm or 808 nm wavelength semiconductor laser. Maximum output power is 10 mW. The following warning label is placed on the scanner housing:



The following safety measures should be taken while operating the scanners:

- Do not target laser beam to humans.
- Do not disassemble the scanner.
- Avoid staring into the laser beam.

4. General information

The Seam Tracking System is designed to be used in robotic welding systems and is intended to automatically control the position of the welding head during the welding process.

5. Structure

The system includes the following components:

- Laser scanner RF627Weld.
- Riftek Lamia software.
- Controller (optional).
- Cables.
- Calibration plate.

5.1. Laser scanner

The system includes a laser scanner (RF627Weld Series) equipped with an air-cooling system, replaceable glasses and a special attachment mechanism designed to fix the scanner to the welding robot.

The housing of the scanner is made of anodized aluminum. The front panel of the housing has two windows: the output window and the window for receiving radiation reflected from the object under control.

The scanner has one connector, **Reset** button and LED indicators. Pressing the **Reset** button for 5 seconds will restart the scanner. If you press the **Reset** button for 1 second, a broadcast Hello packet will be sent. Red LED indicates that the firmware is loading; green LED indicates that the Ethernet connection is established.

The following configurations are available:

- red laser scanners, 660 nm;
- blue laser scanners (BLUE version), 405 or 450 nm;
- infrared laser scanners (IR version), 808 nm.

We use different lasers due to a wide range of applications. For example, the use of blue lasers instead of red ones is optimal for the control of shiny materials and high-temperature objects.

There are two operating modes in the full working range: Basic mode with the frequency of 484 Hz (profiles/second) and DS mode with the frequency of 938 Hz.

In addition, you can use the ROI function, which makes it possible to increase the working frequency of the scanner in the limited working range up to 5096 Hz in Basic mode and up to 6800 Hz in DS mode.

Specifications, working ranges and overall dimensions are given in section [7.1](#).

5.2. Riftek Lamia software

Riftek Lamia is a multifunctional software application designed to be used in automated industrial systems.

Riftek Lamia is intended for:

- recognizing, tracking and measuring geometric parameters of objects (for example, welding joints and welds) in real-time mode;
- connecting to the client controller to transmit results;
- data visualization.

A detailed description of Riftek Lamia software is given in section [14](#).

5.3. Controller

The controller is an industrial tablet PC that has Riftek Lamia software installed.



Figure 1

Designations:

1. RJ-45 Ethernet connector.
2. Wi-Fi / Bluetooth antenna.
3. USB 2.0 connectors.
4. Scanner connector.
5. Power button.
6. Power connector.

Since the controller has the Wi-Fi antenna, the user can connect to the controller via a remote desktop or via the SSH protocol by creating an access point.



The controller comes optional. Instead of the controller, the customer can use a PC with Riftek Lamia software installed and a power supply unit.

Technical characteristics and overall dimensions are given in section [7.2](#).

6


5.4. Cables

The system comes with three cables:

1. UNITRONIC® LiYCY (TP) cable.
2. RJ-45 Ethernet cable.
3. Power cable.

5.4.1. UNITRONIC® LiYCY (TP) cable

The UNITRONIC® LiYCY (TP) cable is used to connect the scanner to the controller.



Designations:

Name	Description
X1	Binder 423 99 5456 15 16
X2	RJ-45
1	LAPP KABEL UNITRONIC® LiYCY (TP) cable, #0035150, 8x2x0.14

Assignment of cable wires is given in the table below:

Pin number	Wire color	Assignment
K	Pink	MX4-
L	Gray	MX4+
M	Red	Power 9...36V
N	Blue	0V GND
A	Black	MX3-
B	Violet	MX3+
C	Brown / Yellow	IN1-
D	White / Yellow	IN1+
E	Red / Blue	IN3+
F	White	MX2-
O	Brown	MX2+
G	Gray / Pink	IN3-
P	Yellow	MX1-
H	White / Green	IN2+
I	Brown / Green	IN2-
R	Green	MX1+



If the order doesn't include a controller, the UNITRONIC® LiYCY (TP) cable will be compressed to RJ-45 Ethernet and two power wires (red and brown).

5.4.2. RJ-45 Ethernet cable

The RJ-45 Ethernet cable is used to connect the scanner controller to the robot controller.

5.4.3. Power cable

The power cable is used to connect the scanner controller to 220V AC.

5.5. Calibration plate

The calibration plate is used to calibrate the scanner relative to the welding robot. The calibration procedure is described in section [14.7.7.](#)

6. Operating principle

The laser scanner is mounted on the flange of the robot next to the welding torch. The scanning area is located directly in front of the welding electrode at a distance of several centimeters. The scanner controller processes the information received from the scanner in accordance with the selected mathematical algorithm that determines the exact coordinates of the welding joint. In real time, the scanner controller transmits the coordinates to the robot controller, and the robot controller corrects the position of the welding torch during the welding process.

7. Basic technical data

7.1. Laser scanner

7.1.1. Specification

Sampling rate, accuracy, resolution	
Nominal sampling rate (full working range)	484 profiles/s (standard mode), 938 profiles/s (DS mode)
Maximum sampling rate (ROI mode)	5096 profiles/s, 6800 profiles/s (DS mode)
Linearity (measurement error), Z axis	±0.05% of the range (standard mode), ±0.1% of the range (DS mode)
Linearity (measurement error), X axis	±0.2% of the range
Resolution, Z axis	0.01% of the range (standard mode), 0.02% of the range (DS mode)
Resolution, X axis	648 or 1296 points (programmable value)
Laser	
660 nm or 405 nm or 450 nm or 808 nm Class 2M according to IEC/EN 60825-1:2014	
Interface	
Basic	Ethernet / 1000 Mbps
Synchronization inputs	RS422, 3 channels
Power supply	9...30 V or 12...39 V for scanners with Blue laser
Power consumption, not more	6 W (without a built-in heater)
Environmental resistance	
Enclosure rating	IP67
Vibration	20 g / 10...1000 Hz, 6 hours for each of XYZ axes
Shock	30 g / 6 ms
Operating ambient temperature	-20...+40°C or -20...+120°C for scanners with built-in air cooling system
Storage temperature	-20...+70°C
Relative humidity	5-95% (no condensation)
Housing/windows material	aluminum/glass

7.1.2. Working ranges and overall dimensions

Range	MR, mm	SMR, mm	Xsmr, mm	Xemr, mm	Size, mm	Weight, g
68/25-22/24	25	68	22	24	Figure 2	0.7
69/130-35/130	130	69	35	130	Figure 3	0.7
91/250-65/180	250	91	65	180	Figure 4	0.7

Detailed CAD documentation (2D and 3D) is available on request at support@riftek.com.

Overall and mounting dimensions of laser scanners:




Figure 2





Figure 3


Figure 4
10

7.2. Controller

7.2.1. Specification

Parameter		Value
Screen size		10"
Screen resolution		1366x768
Screen type		IPS
Operating system		GNU/Linux
RAM		2 GB
Internal memory		32 GB
Power supply		220 V
Environmental resistance	Relative humidity	5-95% (no condensation)
	Operating ambient temperature	0...+45 °C
	Storage temperature	-20...+65 °C
Housing material		aluminum
Weight, gram		2500

7.2.2. Overall dimensions

Overall and mounting dimensions of the controller are shown in Figure 5:




Figure 5

8. Example of item designation when ordering

RF627Weld.(WAVE)-SMR/MR-Xsmr/Xemr-M(R)-AC-C

Symbol	Description
(WAVE)	Laser wavelength. 660 nm – no symbol, 405 nm or 450 nm – BLUE, 808 nm – IR.
SMR	Beginning of the measuring range for Z, mm.
MR	Measuring range for Z, mm.
Xsmr	Measuring range for X-coordinate at the beginning of the measuring range for Z-coordinate, mm.
Xemr	Measuring range for X-coordinate at the end of the measuring range for Z-coordinate, mm.
M	Cable length, m.
R	Option, robot-cable.
AC	Built-in air cooling system. Ordering a water cooling system requires consultation with the manufacturer.
C	Controller.

Example. RF627Weld.BLUE-70/50-30/42-5-AC-C – Scanner with a blue laser, SMR - 70 mm, MR - 50 mm, Xsmr - 30 mm, Xemr - 42 mm, cable length - 5 m, air cooling system, controller.

9. Overall demands for mounting

The laser scanner is mounted on the robot flange next to the welding torch. The scanning area must be within the working range of the scanner. In addition, no foreign objects should be allowed to stay on the path of the incident and reflected laser radiation.

When scanning a surface with an intricate texture, the incidence of mirror component of the reflected radiation to the receiving window should be minimized.


ATTENTION!

The scanner and controller must be grounded. Static electricity may cause the failure of electronic components. To ground the controller, use the DIN rail.

10. Ethernet interface

Profiles are transferred between the scanner and the controller over the UDP protocol, the structure of packets is described in the Developer Guide. Download link:


https://riftek.com/media/documents/rf627/soft/RF627_Software_Tools_eng.pdf

11. Network configuration

All scanners are shipped with the following network configuration unless otherwise specified in the order:

- Autonegotiation of connection speed (100/1000 Mbps)
- IP address of the scanner: 192.168.1.30
- Subnet mask: 255.255.255.0
- Gateway: 192.168.1.1
- Host IP address (device that receives profiles): 192.168.1.2
- Host port that receives data: 50001
- HTTP connection port (for connecting a browser): 80
- Service port of the scanner: 50011
- Ethernet/IP service port: 44818

If the order doesn't include a controller, it is necessary to configure the network card of the PC in the 192.168.1.* address space. An example:



The screenshot shows the 'General' tab of a network configuration window. It contains the following text and controls:

- Text: "You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings."
- Radio button: "Obtain an IP address automatically" (unselected).
- Radio button: "Use the following IP address:" (selected).
- Form fields for manual IP configuration:
 - IP address: 192 . 168 . 1 . 5
 - Subnet mask: 255 . 255 . 255 . 0
 - Default gateway: . . .
- Radio button: "Obtain DNS server address automatically" (unselected).
- Radio button: "Use the following DNS server addresses:" (selected).
- Form fields for manual DNS configuration:
 - Preferred DNS server: . . .
 - Alternate DNS server: . . .
- Button: "Advanced..."
- Buttons: "OK" and "Cancel" at the bottom.

NOTE: Ethernet Jumbo frames are not supported by the scanner.

12. Connection procedure


System with controller		System without controller *	
#	Description	#	Description
1	Connect the scanner to the controller using a UNITRONIC® LiYCY (TP) cable.	1	Connect the scanner to the PC using a UNITRONIC® LiYCY (TP) cable compressed to RJ-45 Ethernet and two power wires.
2	Connect the scanner controller to the robot controller using an RJ-45 Ethernet cable.	2	Connect the PC to the robot controller using an RJ-45 Ethernet cable.
3	Connect the scanner controller to 220V AC using a power cable.	3	Connect the scanner to the power supply unit (red wire is a "plus" of the power supply unit, brown wire is a "minus" of the power supply unit).
4	Switch on the scanner controller by pressing the power button.	4	Make network settings as described in the previous section.
		5	Supply power to the system (9...30 V, or 12...39 V for scanners with blue laser).

NOTE 1: Within 8 seconds after powering on, the FPGA firmware is booting and the Ethernet interface is initializing (the red LED blinks). After that, the system is ready to operate (the green LED blinks).

NOTE 2: To turn off the system, press the power button on the controller, or turn off the power supply (for the system without controller).

13. Setting parameters of the scanner. Web page







The web page is intended to check the operation and configure parameters of the scanner. To access the web page, enter the IP address of the scanner into the address bar of the web browser:



The web page contains four areas (shown above):

1. Scanner status indicators.
2. Parameterization tabs.
3. Result and status display tabs.
4. Control buttons.

Area 1 contains the following indicators:

Icon	Name	Description
	Device info	Model name and serial number of the scanner. Serial number is a unique identifier of the scanner and is assigned by the manufacturer.
	Connection status	The status of connection with the scanner. If the connection is established, the Link caption and the connection speed value will be displayed in this field. The Required caption displays the recommended connection speed required for correct operation of the device. The recommended speed depends on the operation mode of the scanner. If communication with the scanner is lost (for example, when the scanner is restarted or the connection is broken), the web page will be displayed, but the connection status will change to Disconnected .
	Triggering mode	Measurement triggering mode, in which the scanner is operating now.
	Profile settings	The current profile data format (Format) and the current number of profiles per second (FPS) sent by the scanner via the UDP protocol. The value may vary depending on the operating mode of the scanner and its settings.
	Temperature °C	Processor temperature (CPU) and internal temperature of the scanner (Internal) in °C. This information is used to assess the operating conditions of the scanner. Do not allow the temperature to rise to 90°C or more. When the permissible temperature is exceeded, the indicator starts blinking.
	Total work time	Operating time after switching on (Work) and total operating time of the scanner (Total).



Area 2 contains the following tabs:



- **General.** General scanner settings, including parameters of CMOS-sensor and data streams.
- **Profile processing.** Profile processing settings and control of profiles accumulation in scanner memory.
- **Network.** Network settings of the scanner.
- **Triggering.** Settings of input channels of the scanner (triggering modes) and output channel for synchronization of work of several scanners.
- **System.** System settings of the scanner, including support for compatibility modes, etc.

Area 3 contains the following tabs:

- **Info.** General information about the scanner (firmware version, working range, etc).
- **Viewer.** Viewing the current profile, or viewing profiles accumulated in internal memory with the ability to display as a 3D point cloud, or viewing the intensity image.
- **Video.** Video signal view.
- **Log data.** Information about the scanner operation.

Area 4 is located in the upper right corner and contains the control buttons:

Button	Name	Description
	Save configuration	Save settings to the flash memory of the scanner.
		The exclamation mark means that the parameters have been changed, but haven't been saved.

Button	Name	Description
	Load defaults	Restore the factory settings. Important: It is necessary to restart the scanner after restoring the factory settings. Click the Restart device button.
	Restart device	Restart the scanner.

A detailed description of all settings is given in the User's Manual for Laser Scanners RF627 Series:

https://riftek.com/media/documents/rf627/manual2019/2D_Laser_Scanners_RF627_Series_eng.pdf

14. Riftek Lamia software

The Riftek Lamia software starts automatically after the controller is turned on. For the system without controller, the Riftek Lamia software must be installed on the PC or laptop.



ATTENTION!

1. Before working with Riftek Lamia, it is necessary to enable the **Protocol backward compatibility** mode on the web page of the scanner (see section 23.2. of the User's Manual for Laser Scanners RF627 Series).
2. Do not use Riftek Lamia to configure scanner settings or update firmware. For these purposes, you must use the web interface.

14.1. System requirements

The main requirements for using Riftek Lamia:

- Operating system Windows 7 and later, or GNU/Linux.
- Video card and video card drivers, which support OpenGL 2.1 and later, or GLES 3.0 and later.

NOTE (for OS Windows only): To avoid errors in the software operation, you must install the latest graphics card driver provided by the supplier (not by the operating system).

Radeon video card drivers: <http://support.amd.com/en-us/download>.

GeForce video card drivers: <http://www.geforce.com/drivers>.

14.2. Installation

Before starting the installation process, read the following information.

The Riftek Lamia software is designed for 64-bit operating systems. To determine the version of your operating system, refer to the System Properties window or to your system administrator.

Download links:

Windows x64:

https://riftek.com/media/documents/software/lamia/LamiaInstaller_win_x86_64.zip

Linux x64:

https://riftek.com/media/documents/software/lamia/LamiaInstaller_linux_x86_64.zip

To start the installation process, you need to run the setup file:


- LamiaInstaller_win_x86_64.exe, or
- LamiaInstaller_linux_x86_64.exe

When you run the setup file, the welcome window of the Setup Wizard appears. In this window, you need to click **Next >** and follow the guidelines in dialog boxes of the Setup Wizard.

14.3. User's interface description

14.3.1. Main window








The main window:



Main panels:


Panel	Description
SEARCH	Search for scanners and connection.
MATHS	Seam tracking and measurement.
PROTOCOLS	Protocols for communication with industrial robots.

Toolbar:

Icon	Assignment
	Hide / show the left panel.
	Switch to the full screen mode.
	Exit the full screen mode.
	Open the "Settings" window: application settings, language selection, and so on.
	Open the "Tools" window: emergency commands.
	Open the "About" window: information about Riftek Lamia, license activation.
	Close Riftek Lamia.

14.3.2. "Settings" window

To open the **Settings** window, click  in the toolbar. The **Settings** window:




Program settings:

Item	Description
Save application log	Save the application log to the file app-log.txt.
Dump profiles	Save each profile to a separate CSV file.
Shift Z	This option shifts the obtained profile down for the half of the Z range. Always enable this option before connection to the special scanners with the inverted Z coordinate.
Search on start	Start the search for the scanners automatically when you start the software.
Use compact UI	The desktop version of the user interface. If this option is disabled, the mobile version will be used.
Use virtual keyboard	Enable virtual keyboard.
Use system font	Use the operating system font.
Use desktop OpenGL	Accelerate the rendering speed for the user's interface.
Language	Select the application language: English or Russian.
OPEN PROFILES DIRECTORY	Open the folder with profiles.
BACKUP LAMIA SETTINGS	Save current custom settings (all Riftek Lamia settings, license, and math templates) to backup.
RESTORE LAMIA SETTINGS	Restore settings from backup.
RESET LAMIA SETTINGS	Reset all program settings: delete all user settings, log files and deactivate the license.

14.3.3. "Tools" window

To open the **Tools** window, click  in the toolbar. The **Tools** window:



In order to send the command to the scanner, enter its serial number into the **Serial number** field, and click the button.


Button	Assignment
LASER ON	Switch on the laser.
LASER OFF	Switch off the laser.
FACTORY RESET	Reset all settings to factory values.
REBOOT	Reboot the scanner.
SHUTDOWN	Shutdown the scanner.
DROP CONNECTIONS	Drop all active connections.
FLUSH PARAMETERS	Save parameters to the non-volatile memory of the scanner.






When working with RF627 scanners, only the "LASER ON" and "LASER OFF" commands can be used.

14.3.4. "About" window

To view information about **Riftek Lamia**, click **?** in the toolbar. The **About** window:



To activate the license, enter the email and the license key into the appropriate fields. To view information about the license, click **VIEW LICENSE DETAILS**. The information is presented on three tabs:




14.3.5. Keyboard shortcuts

Alt + 1	Show the SEARCH panel.
Alt + 2	Show the MATHS panel.
Alt + 3	Show the PROTOCOLS panel.
Ctrl + B	Switch to the Background maths mode.
Ctrl + F	Start the search for devices.
Ctrl + H	Hide / show the left panel.
Ctrl + Q	Close Riftek Lamia.
Ctrl + W	Drop the TCP connection.
Ctrl + Shift + O	Open the Settings window.
F1	Open the About window.
F11	Switch to the full screen mode.

14.4. Search for scanners


To start searching for scanners, click the **SEARCH** button, or use the keyboard shortcut **Ctrl + F**. In addition, you can enable the **Search on start** option in the **Settings** window to start the search automatically when you start the program.

When the scanner is detected, the program activates two panels: TCP connection and UDP stream:



20

On the TCP panel, you can see the series and the IP address of the scanner. On the UDP panel, you can see the series and the UDP port number of the scanner. For more information about the scanner, click the "i" icon.



Information about the scanner:


s/n	Serial number.
Z Base	Base distance, mm.
Z Range	Measurement range, mm.
X SMR	The range by X coordinate at the beginning of the working range by Z, mm.
X EMR	The range by X coordinate at the end of the working range by Z, mm.
MAC	MAC address.
Firmware	Firmware version.





The TCP panel is not used when working with RF627 scanners.

14.5. Connection

Clicking on the UDP panel requests the UDP stream from the corresponding scanner and activates the visualization panel, on which the obtained profile is displayed.



You can hide the **SEARCH** panel by clicking the button  or by using the keyboard shortcut **Ctrl+H**.



By moving the object or the scanner, observe changes in the profile. Zooming is performed by rotating the mouse wheel. To move the profile, press the left mouse key and drag.

The status line in the lower part of the window shows:


Points	Number of valid points in a profile.
Packet	Number of received packets.
Measurement	Number of received profiles (scanner internal counter).
P.speed	Packet reception rate.
M.speed	Measurement speed.

To disable the UDP stream, you need to click on the UDP panel.

14.6. Selecting a template for seam tracking. "MATHS" panel

14.6.1. General information

The **MATHS** panel contains two sets of built-in templates: **Measurement** and **Welding**. By default, the **Measurement** set is selected. To work with the **Welding** set, click on the list of sets at the lower left corner of the window and select **Welding**. You will see:



22

Riftek Lamia automatically recognizes the weld seam for tracking in accordance with the selected math algorithm (template). There is no need to set the tracking area manually.







To select a template, you need to click on its icon. After selecting, **Riftek Lamia** automatically finds an appropriate profile and displays the calculated parameters. These parameters are sent to the robot controller in accordance with the selected protocol.

The user can configure template settings, change the order, remove unnecessary templates, or add the new ones.

The area of templates contains the button intended to add templates to the area -





The toolbar description:

Element	Description
	Apply the math algorithm (template). If you disable this option, the area of templates will not be active.
	The Robot view option. When this option is enabled and connection with the robot is established, the template requested by the robot will be selected automatically. When the Robot view option is enabled, the area of templates is not active.
	Restore a default set of templates.
	Show template settings.
	Copy the selected template.
Set	Select a set of templates: Welding or Measurement.
	Edit mode.






14.6.2. Search parameters ("SEARCH" tab)

The image obtained from the scanner is not an exact copy of the object profile and may contain gaps, false images and noises caused by, for example, the surface heterogeneity, laser reflections, influence of the external light sources and electrical noise, and so on. Optimal search parameters make it possible to find the profile on the image, which is the most similar to the selected template.

To configure search parameters, it is necessary to double-click on the template icon, or click one time and then click . The search parameters are displayed on the **SEARCH** tab:



Buttons assignment:


Button	Assignment
	Go back to the main panel.
	Save and apply changes for the selected template.
	Save and apply changes of some parameters for all templates (works only for "Invalid sequence", "Search distance", "2D offset X", "2D offset Z"). This button will be active after clicking  .
	Reset all changes to the last saved settings.

Search parameters:

Parameter	Factory value	Description
Global options	On	Select this option to display and use global (common) search parameters for all templates, or disable this option to set different search parameters for templates.
X coordinate	0	X coordinate of the profile point in accordance with which the Y coordinate will be calculated.
Minimum plane length	10	The minimum length of a plane area on the profile. Unit of measurement - millimeters.
Minimum hill height	1	The minimum height of the hill area over the flat area. Unit of measurement - millimeters.
Inverse search	Off	Invert the Z coordinate.

Parameter	Factory value	Description
Search position (Projection, Center of mass, Top, Butt center)	Projection	Search for a point in accordance with the set position: Projection – a projection of the highest point onto a plane, Center of mass – a center of mass of a hill, Top – the highest point, Butt center - a middle point between two joining surfaces.
Circle criterion	0.1	The maximum value of the circle quality, with which a profile will be defined as a circle. The circle quality = the standard deviation of the profile points from the circle / circle radius. The range of values: 0..1 (the higher the value, the "worse" the circle). The "0" value is supposed to be set for detecting a perfect circle.
Maximum distance between points*	2	* See a description in the Table below.
Maximum line half-width*	1	
Minimum line length*	4	
Cut-Off border state	Off	Enable / Disable the border, beyond which the found points are not valid.
Cut-Off border range, %	5	The size of the cut-off border. This parameter specifies a percentage of reducing the range of valid values.
Search distance	15	The distance from the previous point, within which the emergence of a new point is valid. Unit of measurement - millimeters.
Invalid sequence	20	The number of invalid points. The points are considered invalid if the distance between these points is greater than the "Search distance". After the end of the invalid sequence, a new point will be taken as valid.
Search range	1.5	The tolerance for the "X coordinate" parameter. Unit of measurement - millimeters.
3D offset X	0	3D offset of one point selected in the "Select" tab. These parameters are applied only for the Riftek P2 protocol.
3D offset Y	0	
3D offset Z	0	
2D offset X	0	2D offset of all points selected in the "Select" tab. These parameters are applied for all protocols.
2D offset Z	0	

* The scanner obtains a profile as a set of points. When searching for a template in a profile, the software combines points into contour lines in accordance with the rules described in the Table below.

Rule	Description
Maximum distance between points	<p>This rule sets the maximum distance between points along Z axis. If the distance between points is less than this value, these points will be taken as one contour line. Unit of measurement - millimeters. An example of splitting the profile into contour lines:</p> 
Maximum line half-width	This rule sets the maximum distance from a point to a line. If the distance is less than this value, the point will be considered belonging to this line. Unit of measurement - millimeters.
Minimum line length	This rule sets the minimum length of the line. All lines, which less than this value, will be considered as a noise, and will be cut off. Unit of measurement - millimeters.



When you have changed search parameters, it is necessary to save them in order for the changes to take effect.

14.6.3. Template parameters ("TEMPLATE" tab)

Templates consist of the lines (profile lines that the scanner "sees"). These lines are numbered starting from "0". The length and position of the lines are determined by special parameters called *constraints*. To view / configure template parameters, double-click on the template icon and go to the **TEMPLATE** tab.

The **TEMPLATE** tab contains a list of constraints that form a template description.

Each constraint is shown as follows:


- Name of the constraint.
- Line index (starts from 0).
- Parameters for the specific constraint type.



When you have changed template parameters, it is necessary to save them in order for the changes to take effect.


There are six types of constraints:

1. Line length




The constraint of the line length (L). This constraint is defined by the lower and upper boundaries set in millimeters ("Minimum" and "Maximum" fields respectively). One or both boundaries may be set as "Undefined".

2. Endpoint distance



The constraint of the distance (L) from the end of one line (*LineFrom*) to the start of another line (*LineTo*). This constraint is defined by the lower and upper boundaries set in millimeters ("Minimum" and "Maximum" fields respectively). One or both boundaries may be set as "Undefined".


3. Rotation angle



The constraint of the angle of rotation ($Angle$) in degrees from one line (*LineFrom*) to another line (*LineTo*). This constraint is defined by the lower and upper boundaries set in millimeters ("Minimum" and "Maximum" fields respectively), and by the direction of rotation. If any of the constraints is absent, set the values "Undefined" and "None" for lower / upper boundaries and for the direction of rotation respectively.


NOTE: The minimum and maximum values of the angle of rotation can vary in the range of 0 to 180°.

4. Endpoint shift in direction




The constraint of shift of the starting point of a line (*LineTo*) relative to the end of another line (*LineFrom*). This constraint is defined by the lower and upper boundaries set in millimeters ("Minimum" and "Maximum" fields respectively). If any of the constraints is absent, it must be set as "Undefined". The direction of shift is defined by "Angle" that varies in the range of -180° to 180° counterclockwise relative to the *LineFrom* line (if the **Angle from the starting line** checkbox is selected), or to the *LineTo* line (if the **Angle from the starting line** checkbox is not selected).

5. Endpoint distance with check



This constraint is similar to *Endpoint distance*, but has an additional verification on the subject that the distance (L) from the end of one line (*LineFrom*) to the start of another line (*LineTo*) is less than the distance between other ends (La). This prevents the situation, in which the wrong lines can be used, because formally they can fit in the constraints.

6. Inclination angle



The constraint of the inclination angle (*Angle*). This constraint is defined by the lower and upper boundaries ("Minimum" and "Maximum" fields respectively). If any of constraints is absent, it must be set as "Undefined".

NOTE: The values can vary in the range of -180° to 180° , positive values correspond to the counterclockwise rotation.

14.6.4. List of measurements ("SELECT" tab)


The **SELECT** tab contains a list of measurements for the selected template.



When you have changed a list of measurements, it is necessary to click ☒ in order for the changes to take effect.


There are nine measurement types:

1. Line length




The line length in mm.

2. Intersection point




The coordinates (X, Y) of the intersection point.

3. Rotation angle




The rotation angle (*Angle*) between the *LineFrom* line and the *LineTo* line.

4. Line point




The coordinates (X, Y) of a specific point on the line. This measurement is defined by the "position" parameter, where "0" is the start of the line, and "1" is the end of the line (values outside of the range [0; 1] are possible).

5. Far line in direction




The coordinates of the two extreme points of the farthest line (*farPoint* and *nearPoint*), and the inclination angle of this line. The direction is defined by a nonzero vector ("direction"), the rotation angle of which is measured counterclockwise and varies in the range from -180° to 180° .

6. Angle between lines




The angle between lines *LineFrom* and *LineTo* from above. The values can vary in the range from 0° to 360° .

7. Inclination angle




The inclination angle (*Angle*) of the line. The values can vary in the range from -180° to 180° ; positive values correspond to the counterclockwise rotation.

8. Point between 2 points



The measurement of the point position on the line between other two points. This position is defined by the "position" parameter, where "0" is the start of the line, and "1" is the end of the line.

9. Endpoint shift in direction



The measurement of the endpoint shift (D) of the *LineTo* line relative to the endpoint of the *LineFrom* line along the direction. The direction of shift is defined by the angle (*Angle*), which is measured counterclockwise relative to the *LineReference* line and varies in the range from 180° to 180° .

14.6.5. Built-in templates


The software offers two sets of built-in templates: **Measurement** and **Welding**. These sets are designed to be used for recognizing, tracking and measuring geometric parameters of different objects. The **Welding** set was specially created to be used for robot welding.

By default, the software shows the **Measurement** set. To change a set, click on the list of sets at the lower left corner of the window and select **Welding**.

Every template description contains a table with the following columns:


- **Constraints** - a list of constraints applied for this template (see section [14.6.3](#)).
- **Measurements** - a list of measurements performed by this template (see section [14.6.4](#)).
- **Parameters** - a list of search parameters applied for this template (see section [14.6.2](#)).



The Tuning template  does not work with RF627 scanners.

14.6.5.1. Template 1 "Fillet weld"

Template 1 is intended to be used for fillet welds. The algorithm looks for two profile lines and calculates coordinates of their point of intersection. This point of intersection can be used as the tracking point.




Constraints	Measurements	Parameters
Endpoint distance with check <ul style="list-style-type: none"> Distance between lines 0 and 1; the minimum distance is undefined, the maximum distance is 20 mm. Rotation angle <ul style="list-style-type: none"> Angle of rotation from line 0 to line 1 (30°...150°); the direction of rotation is undefined. 	Lines intersection <ul style="list-style-type: none"> Intersection point of lines 0 and 1. 	-

14.6.5.2. Template 2 "Corner weld"

Template 2 is intended to be used for corner welds. The algorithm allows the user to select the tracking point:

- Corner point, or
- Midpoint




30

Constraints	Measurements	Parameters
Endpoint distance with check <ul style="list-style-type: none"> Distance between lines 0 and 1; the minimum distance is undefined, the maximum distance is 5 mm. Distance between lines 1 and 2; the minimum distance is undefined, the maximum distance is 5 mm. Distance between lines 2 and 3; the minimum distance is undefined, the maximum distance is 5 mm. Rotation angle <ul style="list-style-type: none"> Angle of rotation from line 0 to line 1 (60°...120°); the direction of rotation - left. Angle of rotation from line 1 to line 2 (60°...120°); the direction of rotation - right. Angle of rotation from line 2 to line 3 (60°...120°); the direction of rotation - left. 	Lines intersection <ul style="list-style-type: none"> Corner point (intersection point of lines 1 and 2). Point between 2 points <ul style="list-style-type: none"> Midpoint (between the endpoint of line 0 and the starting point of line 3). 	-

14.6.5.3. Template 3 "Lap weld"


Template 3 is intended to be used for lap welds. The algorithm looks for three profile lines and calculates the coordinates of their points of intersection, which can be taken as the tracking points.



Constraints	Measurements	Parameters
Endpoint distance with check <ul style="list-style-type: none"> Distance between lines 0 and 1; the minimum distance is undefined, the maximum distance is 10 mm. Distance between lines 1 and 2; the minimum distance is undefined, the maximum distance is 10 mm. Rotation angle <ul style="list-style-type: none"> Angle of rotation from line 0 to line 1 (60°...120°); the direction of rotation is undefined. Angle of rotation from line 1 to line 2 (60°...120°); the direction of rotation is undefined. 	Lines intersection <ul style="list-style-type: none"> Left point (intersection point of lines 0 and 1). Right point (intersection point of lines 1 and 2). 	-

14.6.5.4. Template 4 "Square-groove butt weld"

Template 4 is intended to be used for square-groove butt welds. The algorithm looks for two profile lines and calculates the coordinates of a middle point between them, which can be taken as the tracking point. The algorithm also calculates the gap width.



32


Constraints	Measurements	Parameters
Line length <ul style="list-style-type: none"> Line 0; the minimum length is 20 mm, the maximum length is undefined. Line 1; the minimum length is 20 mm, the maximum length is undefined. Endpoint distance with check <ul style="list-style-type: none"> Distance between lines 0 and 1; the minimum distance is 2 mm, the maximum distance is undefined. Rotation angle <ul style="list-style-type: none"> Angle of rotation from line 0 to line 1; the minimum value is undefined, the maximum value is 10°; the direction of rotation is undefined. 	Point between 2 points <ul style="list-style-type: none"> Midpoint (between the end point of line 0 and the starting point of line 1). Endpoint shift in direction <ul style="list-style-type: none"> Width (distance between the end point of line 0 and the starting point of line 1). 	-

14.6.5.5. Template 5 "V-groove weld"

Template 5 can be used for V-grooves as well as for U-grooves, J-grooves and bevel grooves.

To select the tracking point, it is necessary to set the **Search position** in the **SEARCH** tab (see section [14.6.2](#)).

The algorithm also calculates the height and width of the groove and the inclination angle of a flat area.




Constraints	Measurements	Parameters
-	<ul style="list-style-type: none"> Point (coordinates of the point set by Search position) Height Width Angle (inclination angle of a flat area) 	<p>Minimum plane length – The minimum length of a flat area, from which the measurement of a hill will start.</p> <p>Minimum hill height.</p> <p>Search position:</p> <ul style="list-style-type: none"> Projection Center of mass Top Butt center

14.6.5.6. Template 6 "Left edge"

Template 6 is intended to be used in a case when the geometry of one side of the groove does not allow to receive a correct information for tracking and the other side gives clear information.

The algorithm looks for the leftmost line of the all profile lines and calculates the coordinates of its right point and the angle of inclination. The right point can be taken as the tracking point.




34

Constraints	Measurements	Parameters
-	Far line in direction <ul style="list-style-type: none"> Right point (coordinates of the right point of the leftmost line). Inclination angle of the leftmost line. 	-

14.6.5.7. Template 7 "Right edge"

Template 7 is intended to be used in a case when the geometry of one side of the groove does not allow to receive a correct information for tracking and the other side gives clear information.

The algorithm looks for the rightmost line of the all profile lines and calculates the coordinates of its left point and the angle of inclination. The left point can be taken as the tracking point.




Constraints	Measurements	Parameters
-	Far line in direction <ul style="list-style-type: none"> Left point (coordinates of the left point of the rightmost line). Inclination angle of the rightmost line. 	-

14.6.5.8. Template 8 "Spot weld"

Template 8 is intended to be used for spot welds.

The algorithm allows the user to set the X-coordinate of the tracking point in accordance with which the Z-coordinate will be calculated. If necessary, the user can set the tolerance for this X-coordinate (**Search range**). Both parameters are customized in the **SEARCH** tab (see section [14.6.2](#)).




36

Constraints	Measurements	Parameters
-	<ul style="list-style-type: none"> Z-coordinate 	<ul style="list-style-type: none"> X-coordinate Search range

14.6.5.9. **Template 9 "Nearest point"**

Template 9 is intended to be used in a case when the tracking point is the nearest point of the profile.


The algorithm calculates the X-coordinate of the tracking point at the minimum Z-coordinate.



Constraints	Measurements	Parameters
-	<ul style="list-style-type: none">X-coordinate of the profile point	-

14.6.5.10. Template 10 "Slope"

Template 10 is intended to be used for finding the edges of sheet metal with the thickness of several millimeters. The algorithm looks for one profile line and calculates its angle of inclination and coordinates of a middle point.





38

Constraints	Measurements	Parameters
Line length <ul style="list-style-type: none"> Line length; the minimum length is 5 mm, the maximum length is undefined. 	Inclination angle <ul style="list-style-type: none"> Inclination angle of the line. Line point <ul style="list-style-type: none"> Midpoint (a middle point of the line). 	-

14.6.6. Operations with templates


14.6.6.1. Adding a template

To add a template into the area of templates, click . The following window appears:







Select a template (or several templates) and click **ADD**.
To close the window, click **CANCEL**.

14.6.6.2. Copying a template

To create a copy, select a template and click . The copied template will be added to the end of the list.

14.6.6.3. Removing a template

Enable the **Edit** mode by clicking . The pictogram  will change its color to green and you will see the "remove" pictogram  on each template:



To remove a template, click .

NOTE 1: The program doesn't prompt to confirm the action, and you cannot restore a template that was removed.

NOTE 2: Always disable the **Edit** mode after editing.


14.6.6.4. Changing the order


Enable the **Edit** mode as described in the previous section.

To change the order, hold the left mouse key pressed and drag the template to the required position.

NOTE: Always disable the **Edit** mode after editing.

14.6.6.5. Restoring a default set of templates

To restore a default set of templates, click . You will be prompted to confirm the action:



Click **SUBMIT** to confirm the action, otherwise – click **CLOSE**.

After confirming, the current set of templates will be replaced with the default one.

14.7. Working with welding robots. "PROTOCOLS" panel

14.7.1. General information


The PROTOCOLS panel contains a set of protocols, which can be used to transmit measurement data to industrial robots. The program offers the following protocols: Riftek P1, R691 USI, Riftek P2, EtherNet/IP. But the Riftek P1 protocol cannot be used for seam tracking.

On the PROTOCOLS panel, parameters and buttons are displayed in accordance with the selected protocol. A detailed description of the protocols, except for Riftek P1, is given in the sections below.



Before using the Riftek P2 and EtherNet/IP protocols, you need to calibrate the scanner. The calibration procedure is described in par. [14.7.7.](#)

14.7.2. Functional diagram



#	Description
1	The scanner transmits data to the controller (or to the PC with the Riftek Lamia software installed).
2	Riftek Lamia processes the data in accordance with the selected math algorithm and transmits the results to the robot controller over the selected protocol.
3	The robot controller makes decisions based on the received information. For example, corrects the position of the welding torch during the welding process.

14.7.3. Connection procedure

To connect to the robot, follow the steps below:

Step	Description
1	Find a scanner by clicking the SEARCH button and connect to it over TCP.
2	Go to the PROTOCOLS panel and click LOCK SENSOR.
3	Return to the SEARCH panel and disconnect from TCP.
4	Start the UDP stream by clicking on the UDP panel.
5	Go to the PROTOCOLS panel, set parameters in accordance with the selected protocol, and enable the State option.


NOTE: Steps 1-3 are performed once when connecting a new scanner. If the scanner has been connected, you just need to follow steps 4-5.

14.7.4. R691 USI protocol

14.7.4.1. General information

The **R691 USI** protocol is based on the client-server model (**Riftek Lamia** is a server, a robot is a client), works over TCP, and uses port 5020 by default.

The **PROTOCOLS** panel with the **R691 USI** protocol selected:



Parameters and buttons:

Parameter	Description
Sensor s/n	Serial number of the scanner.
Sensor target port	UDP port, to which the scanner sends profiles (6003 by default).
Protocol	Protocol selection: Riftek P1, R691 USI, Riftek P2, EtherNet/IP.
Server port	Host PC port (5020 by default).
Timeout, s	Time after which the protocol will be disabled if there are no commands or requests from the robot.
Debug log	Save the debug log: time and type of request from the robot, bytes of commands, the response time of the program, response bytes, error text.
LOCK SENSOR	Lock the scanner to the protocol settings.
Force template change	Forced template change for every received packet.
State	Enable the selected protocol.



When the **State** option is enabled, you cannot change parameters on the **PROTOCOLS** panel, and you cannot connect to the scanner over TCP.

14.7.4.2. Client (robot) requests

The robot sends requests to the scanner by packets of at least 3 bytes in length.
The first byte indicates if the robot sends a command (02h) or requests data (01h).
The second byte is the number of commands or data for this packet (usually 1).
The third byte indicates the command or the data request.

#	Request	Read / Write (byte 0)	Number of variables	Command or Data	Value
1	Sensor On	02h	01h	13h	01h
2	Sensor Off	02h	01h	06h	00h
3	Start track (Laser on and measure)	02h	01h	06h	01h
4	End track (Laser off)	02h	01h	06h	00h
5	Set joint ID	02h	01h	10h	xx (joint number in hex)
6	Request joint data	01h	06h	08h 09h 0Ah 0Bh 0Ch 0Dh *	
7	Request status	01h	01h	06h	—
8	Request joint ID	01h	01h	10h	—

The robot waits for a response from the scanner for 80 ms.

After 80 ms without a response, the robot sends the same request again.

After 300 ms without a response, a Timeout Alarm will be posted and the connection will be broken.

*** Request 6 (Request joint data) requests six values in the following order:**

- | | |
|-------------|------------------|
| 1. Offset X | 4. GAP |
| 2. Offset Y | 5. MISMATCH |
| 3. Offset Z | 6. AREA (Region) |

Measurements are sent to the robot in accordance with the selected template.

The Welding set:

Template #	Measurements
1	Offset Y: the X coordinate of the intersection point of two lines Offset Z: the Z coordinate of the intersection point of two lines
2, 3	Offset Y: the X coordinate of the selected point Offset Z: the Z coordinate of the selected point Note. If there are more than one point selected, only coordinates of the first point will be sent to the robot.
4	Offset Y: the X coordinate of the center point Offset Z: the Z coordinate of the center point Gap: gap width
5	Offset Y: the X coordinate of the point set by "Search position" Offset Z: the Z coordinate of the point set by "Search position"
6	Offset Y: the X coordinate of the most right point Offset Z: the Z coordinate of the most right point
7	Offset Y: the X coordinate of the most left point Offset Z: the Z coordinate of the most left point
8	Offset Y: the X coordinate set by the user Offset Z: the Z coordinate in accordance with the set X coordinate
9	Offset Y: the X coordinate of the lowest point along the Z axis Offset Z: the Z coordinate of the lowest point along the Z axis
10	Offset Y: the X coordinate of the center point Offset Z: the Z coordinate of the center point

14.7.4.3. Scanner answers

For commands 1-5 (see [Client \(robot\) requests](#)), the scanner answers with only one byte (82h).

For requests 6-8, the scanner answers as follows: the first byte is 82h, the second byte is an error code, then two bytes for each value (high byte, low byte).

14.7.4.4. Error codes

Error code	Description
0	No error.
1	External alarm (not used).
2	Invalid checksum (not used).
3	Correction (not used).
4	Timeout (not used).
5	Camera alarm (not used).
6	Bad end (not used).
7	Correct message (not used).
8	Unknown parameter (not used).
9	Setup error (not used).
10	Temperature alarm (not used).
11	Value out of range (not used).
12	Data not available (joint not found).

14.7.4.5. Scanner status

For request 7 (status request), the robot expects a 16-bit status word with the following meaning:

Bit number	Value	Decimal bit value
0	No Alarm	1
1	No External Alarm	2
2	No Temperature Alarm	4
3	Not too cold	8
4	Not too hot	16
5	No shut down	32
6	Laser Off	64
7	Laser Down	128
8	Laser Power control disabled	256
9	Flash Checksum invalid	512
10	Calibration Data missing	1024
11	Laser Ready(0x800)	2048
12	Laser On(0x1000)	4096
13	Reserved	8192
14	Reserved	16384
15	Reserved	32768

NOTE: Bits 6, 11, 12 must be set by the scanner and will be used by the robot. Data values are transmitted in the two's complement system.

14.7.4.6. Example

Robot request for status:

[01H] [01H] [06H]

Sensor answer:

[82H] Answer from sensor

[00H] No error

[08H] High byte of status1

[40H] Low byte of status1

Decimal:

08H*256 2048

40H + 64

= 2112

64 = Bit 6 > Laser Off

2048 = Bit 11 > Laser Ready (0x800)

14.7.5. Riftek P2 protocol

14.7.5.1. General information

Modbus TCP protocol.


The **Riftek P2** protocol is based on the client-server model (a robot is a client, **Riftek Lamia** is a server), works over TCP, and uses port 502 by default.

The server does not consider the device address, and responds to any Modbus TCP command.

The data is transmitted through the reading / writing of holding registers. Command codes:

Command code	Description
0x03	Read holding registers.
0x10	Write holding registers.

The **PROTOCOLS** panel with the **Riftek P2** protocol selected:



Sensor s/n: 0

Sensor target port: 6003

Protocol: Riftek P2

Server port: 5020

Timeout, s: 60

☐ Debug log

CALIBRATION

LOCK SENSOR

☐ Force template change

☐ State

Parameters and buttons:

Parameter	Description
Sensor s/n	Serial number of the scanner.
Sensor target port	UDP port, to which the scanner sends profiles (6003 by default).
Protocol	Protocol selection: Riftek P1, R691 USI, Riftek P2, EtherNet/IP.
Server port	Host PC port (502 by default).
Timeout, s	Time after which the protocol will be disabled if there are no commands or requests from the robot.
Debug log	Save the debug log: time and type of request from the robot, bytes of commands, the response time of the program, response bytes, error text.
CALIBRATION	Show the "Calibration" panel. NOTE: This button is active only when the "State" option is enabled.
LOCK SENSOR	Lock the scanner to the protocol settings.
Force template change	Forced template change for every received packet.
State	Enable the selected protocol.



1. It is necessary to calibrate the scanner before using this protocol. See the "Scanner calibration" section.
2. When the **State** option is enabled, you cannot change parameters on the **PROTOCOLS** panel, and you cannot connect to the scanner over TCP.

14.7.5.2. Holding registers

Read holding registers:

16 bit	15 bit	Scanner 3D Point X * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	15 bit	Scanner 3D Point Y * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	15 bit	Scanner 3D Point Z * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	8 bit	The latest counter that was received from the robot (unsigned).
	8 bit	Reserved.
16 bit	15 bit	Robot P * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	15 bit	Robot R * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	15 bit	Scanner 2D Point X * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	15 bit	Scanner 2D Point Y * 10 (absolute value).
	1 bit	Least significant sign bit.

Write holding registers:

16 bit	15 bit	Robot X * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	15 bit	Robot Y * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	15 bit	Robot Z * 10 (absolute value).
	1 bit	Least significant sign bit.

16 bit	8 bit	Robot W * 10 (absolute value).
	8 bit	Least significant sign bit.
16 bit	15 bit	Robot P * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	15 bit	Robot R * 10 (absolute value).
	1 bit	Least significant sign bit.
16 bit	8 bit	Packet counter (unsigned).
	8 bit	Command (unsigned): 0 - no command, 1 - laser ON, 2 - laser OFF. If the command is the same as previous, nothing will happen.
16 bit	8 bit	Template set selection (unsigned): 0 - Measurement, 1 - Welding. If the template set number is the same, nothing will happen.
	8 bit	Template selection (unsigned). If the template number is the same, nothing will happen.

14.7.5.3. Operation logic

1) The robot writes at least six registers (will be taken only six, starting with zero) by six coordinates in the following format: 15 bit - value, 1 least significant bit - sign. The float value transmitted by the robot will be multiplied by 10 in order to contain 1 digit after the point.

2) The robot reads at least eight registers. Riftek Lamia returns eight registers, containing:

- 3D coordinates (XYZ) of a point found by a template (in the robot coordinate system);
- 3 angles that were returned by the robot the last time (by a command 0x10);
- coordinates (XZ) of a point found by a template (in the scanner coordinate system).

Each value is multiplied by 10 to be transmitted and occupies 1 register. The format: 15 bit - value, 1 least significant bit - sign.

For any commands different from mentioned here, Riftek Lamia will respond with the garbage values, or write data, which will not be taken into account in Riftek Lamia.

14.7.6. EtherNet/IP protocol

14.7.6.1. General information

EtherNet/IP is an industrial protocol that allows bidirectional data transfer with PLCs. It encapsulates the object-oriented Common Industrial Protocol (CIP).

To EtherNet/IP-enabled devices on the network, the Riftek Lamia information is seen as a collection of objects, which have attributes that can be queried.


The PLC sends a command to establish a connection with the Riftek Lamia. The PLC then periodically queries the attributes of the assembly objects for its latest measurement results. In EtherNet/IP terminology, the PLC is a scanner and the Riftek Lamia is an adapter.

The default EtherNet/IP ports are used. Port 44818 is used for TCP connections and UDP queries. Port 2222 is used for UDP I/O Messaging.

Riftek Lamia supports unconnected or connected explicit messaging (with TCP), as well as implicit (or I/O) messaging (with UDP). For information on explicit messaging assemblies and objects, see the "Explicit messaging" section below.

For information on implicit messaging assemblies and objects, see the "Implicit messaging" section.

The **PROTOCOLS** panel with the **EtherNet/IP** protocol selected:



Parameters and buttons:

Parameter	Description
Sensor s/n	Serial number of the scanner.
Protocol	Protocol selection: Riftek P1, R691 USI, Riftek P2, EtherNet/IP.
Server address	TCP/IP address of the robot controller.
CALIBRATION	Show the "Calibration" panel. NOTE: This button is active only when the "State" option is enabled.
LOCK SENSOR	Lock the scanner to the protocol settings.
State	Enable the selected protocol.



1. It is necessary to calibrate the scanner before using this protocol. See the "Scanner calibration" section.
2. When the **State** option is enabled, you cannot change parameters on the **PROTOCOLS** panel, and you cannot connect to the scanner over TCP.

14.7.6.2. Explicit messaging

Riftek Lamia supports all required objects for explicit messaging, such as the Identity object, TCP/IP object, and Ethernet link object.

14.7.6.2.1. Identity object (class 0x01)

Attribute	Name	Type	Value	Description	Access
1	Vendor ID	UINT	803	Vendor ID	Get
2	Device Type	UINT	12	Device Type	Get
3	Product Code	UINT	32	Product Code	Get
4	Revision	USINT USINT	0.0	Byte 0 - Major Revision Byte 1 - Minor Revision	Get
6	Serial number	UDINT	32-bit value	License number	Get
7	Product Name	SHORT STRING	"RIFTEK_LAMIA"	Lamia Product Name	Get

14.7.6.2.2. TCP/IP object (class 0xF5)

Attribute	Name	Type	Value	Description	Access
1	Status	UDINT	0	TCP interface status	
2	Configuration Capability	UINT	0		
3	Configuration Control	UINT	0	Product Code	
4	Physical Link Object	Structure		Path size (UINT) Path (Padded EPATH)	

Attribute	Name	Type	Value	Description	Access
5	Interface Configuration	Structure		IP Address (UDINT) Network Mask (UDINT), Gateway Address (UDINT) Name Server (UDINT) Secondary Name (UDINT) Domain Name (UDINT)	

14.7.6.2.3. Ethernet link object (class 0xF6)

Attribute	Name	Type	Value	Description	Access
1	Interface Speed	UDINT	1000	Ethernet interface data rate (mbps)	Get
2	Interface Flags	UDINT		Bit 0: Link Status 0 - Inactive 1 - Active Bit 1: Duplex 0 - Half Duplex 1 - Full Duplex	Get
3	Physical Address	Array of 6 USINTs		MAC address (for example: 11 22 33 44 55 66)	Get

48

14.7.6.3. Implicit messaging

Implicit messaging uses UDP and is faster than explicit messaging, and is ideal for time-critical applications. However, implicit messaging is layered on top of UDP. UDP is connectionless and data delivery is not guaranteed. For this reason, implicit messaging is only suitable for applications where occasional data loss is acceptable.

14.7.6.3.1. Assembly object (class 0x04)

For implicit messaging, the Lamia Ethernet/IP object model includes the following assemblies: Input Assembly (instance 0x65), Output Assembly (instance 0x66), Configuration Assembly (instance 0x64).

All assembly object instances are static. Data in a data byte array in an assembly object are stored in the big endian format.

14.7.6.3.2. Input assembly (instance 0x65)

Input assembly:

Information	Value
Class	0x04
Instance	0x65
Attribute Number	3
Length	16 bytes

Input assembly information:

Byte	Name	Description
0-1	3D X coordinate	0-14 bits: 3D X coordinate of scanner * 10 (module) 15 bit: Least significant sign bit
2-3	3D Y coordinate	0-14 bits: 3D Y coordinate of scanner * 10 (module) 15 bit: Least significant sign bit
4-5	3D Z coordinate	0-14 bits: 3D Z coordinate of scanner * 10 (module) 15 bit: Least significant sign bit

Byte	Name	Description
6	Counter	The latest counter received from the robot (unsigned)
7	Reserved	Reserved for future use
8-9	P coordinate	0-14 bits: P coordinate of robot * 10 (module) 15 bit: Least significant sign bit
10-11	R coordinate	0-14 bits: R coordinate of robot * 10 (module) 15 bit: Least significant sign bit
12-13	2D X coordinate	0-14 bits: 2D X coordinate of scanner * 10 (module) 15 bit: Least significant sign bit
14-15	2D Y coordinate	0-14 bits: 2D Y coordinate of scanner * 10 (module) 15 bit: Least significant sign bit

14.7.6.3.3. Output assembly (instance 0x66)

Output assembly:

Information	Value
Class	0x04
Instance	0x66
Attribute Number	3
Length	16 bytes

Output assembly information:

Byte	Name	Description
0-1	X coordinate	0-14 bits: X coordinate of robot * 10 (module) 15 bit: Least significant sign bit
2-3	Y coordinate	0-14 bits: Y coordinate of robot * 10 (module) 15 bit: Least significant sign bit
4-5	Z coordinate	0-14 bits: Z coordinate of robot * 10 (module) 15 bit: Least significant sign bit
6-7	W coordinate	0-14 bits: W coordinate of robot * 10 (module) 15 bit: Least significant sign bit
8-9	P coordinate	0-14 bits: P coordinate of robot * 10 (module) 15 bit: Least significant sign bit
10-11	R coordinate	0-14 bits: R coordinate of robot * 10 (module) 15 bit: Least significant sign bit
12	Counter	Packet Counter (unsigned)
13	Command	Command selection (unsigned): 0 - no command, 1 - turn on the laser, 2 - turn off the laser. NOTE: If the command is identical to the previous sent command, nothing will happen.
14	Set of templates	Choosing a set of templates (unsigned): 0 - Measure, 1 - Welding. NOTE: If the template set number is repeated, nothing will happen.
15	Template	Template selection (unsigned). NOTE: If the template number is repeated, nothing will happen.

Coordinate bits:

2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰	Sign
-----------------	-----------------	-----------------	-----------------	-----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	----------------	------

14.7.6.3.4. Configuration assembly (instance 0x64)

Information	Value
Class	0x04
Instance	0x64
Attribute Number	3
Length	0 bytes


14.7.7. Scanner calibration

14.7.7.1. "Calibration" panel



Calibration is required only for Riftek P2 and EtherNet/IP protocols.

To activate the **Calibration** panel, it is necessary to select the **Riftek P2** or **EtherNet/IP** protocol on the **PROTOCOLS** panel, and click the **CALIBRATION** button. The **Calibration** panel appears:



← Calibration

Robot data:

X: NaN
Y: NaN
Z: NaN
W: NaN
P: NaN
R: NaN

Profile is OK: No

Result:

Plate distance 0.00000
Robot distance 0.00000
Zero point deviation 0.00000
Rotation angle 0.00000

CAPTURE CALIBRATE

Calibration data:



Data	Description
Robot data	Current coordinates of the robot.
Profile is OK	Shows whether the current profile is suitable for calibration or not (Yes / No). The profile is taken from the scanner at the moment when the robot sends the coordinates.
Result	Calibration result (Success / Fail).

Calibration parameters:

Parameter	Maximum valid value	Description
Plate distance	0.2 mm	The standard deviation of all measured points of the plate from a reference plate at each position with a direct translation of coordinates from the reference system of the scanner to the reference system of the plate (test of independent calibrations of the scanner with respect to a plate).
Robot distance	1.0 mm	The standard deviation of all measured points of the plate from a reference plate at each position with indirect translation of coordinates from the reference system of the scanner to the reference system of the plate through the intermediate reference system of the arm and the reference system of the robot (scanner calibration test with respect to the arm).

Parameter	Maximum valid value	Description
Zero point deviation	1.0 mm	The standard deviation of a zero point in the reference system of the scanner ($X=Z=0$) during its translation to the reference system of the scanner through the reference system of the arm, robot and plate (scanner calibration test with respect to the arm).
Rotation angle	0.02 rad	Root-mean-square rotation angle of the reference system of the scanner in its conversion through the reference system of the arm, robot and plate (scanner calibration test with respect to the arm).

Buttons assignment:

Button	Assignment
CAPTURE	<p>Capture the current pair "Robot coordinates + profile". The button is active only when Robot data shows values different from NaN, and when the profile is suitable for calibration. When you click the button, the pair is added to a list below:</p> <div data-bbox="758 712 1045 846" data-label="Image">  </div> <p>To remove a pair from a list, click .</p>
CALIBRATE	Calibrate the scanner. The button is active only when there are at least 3 pairs ("Robot coordinates + profile") in the list.

To go back to the **PROTOCOLS** panel, click .

14.7.7.2. Calibration procedure

1. Place and fix a scanner. Make sure that the scanner is immobile relative to the robot arm.
2. Determine the direction of the X axis of the scanner relative to its housing.
3. Place the calibration plate so that the arrow on the plate and the X axis of the scanner are approximately in the same direction (the angle must be less than 90°).




The plate must be immobile relative to the robot during the calibration.

4. Place the scanner so that a laser line is in the center of the plate, and the Z axis of the scanner is approximately perpendicular to the plate surface as shown in the picture below.



5. Start **Riftek Lamia** to perform the calibration:
 - Click **SEARCH** to find a scanner.

- Connect to the scanner over TCP by clicking on the TCP panel.
 - Go to the **PROTOCOLS** panel and click **LOCK SENSOR**.
 - Go to the **SEARCH** panel and disconnect from TCP.
 - Start the UDP stream by clicking on the UDP panel and go to the **PROTOCOLS** panel.
 - Select **Riftek P2** or **EtherNet/IP** from a list of protocols.
 - Specify the **Server port** (for **Riftek P2**), or the **Server address** (for **EtherNet/IP**).
 - Enable the **Debug log** option (for **Riftek P2**).
 - Enable the **State** option.
 - Click the **CALIBRATION** button to open the calibration panel. When the **State** option is enabled, the **Robot data** must show NaN values for each coordinate. If there is nothing, go back to the **PROTOCOLS** panel, disable the **State** option and enable it again.
6. Make sure that the current position of the scanner is suitable for calibration (the program must show "Profile is OK: Yes"). An example of a profile suitable for calibration is shown in the screenshot below.



7. Click **CAPTURE**. The pair "Robot coordinates + profile" will appear below the buttons.
8. Change the position of the scanner to the most different from the previous ones (be sure to use all the angles and coordinates).
9. Repeat steps 6-8 for different positions (from 7 to 10).
10. Click **CALIBRATE** (not available when there are less than 3 pairs "Robot coordinates + profile"). The calibration process may take a long time.
11. If the result is "Success", make sure that the values of [calibration parameters](#) do not exceed the maximum valid values. Otherwise, it will be necessary to repeat the calibration.
12. The calibration is complete.

For every request from a robot, a scanner gives XYZ coordinates of the found point into the first three registers (in a robot coordinate system), and XZ coordinates of the found point into the last two registers (in a scanner coordinate system). Before the calibration or after the failed calibration, conversion of a point to 3D is performed by using blank conversion rules or incorrect conversion rules respectively, i.e. the scanner will send invalid 3D results in such cases.

15. Maintenance

Laser scanners are virtually maintenance free. As these are optical systems, they are sensitive to dust and sputter on the front windows. Cleaning is best done with a soft cloth. Do not use scratching cleaners or other aggressive media.

It is necessary to remove fingerprints from the windows, because fingerprints degrade the quality of profiles.

In order to remove fingerprints or grease, clean the windows with 20 % alcohol and soft paper.

16. Troubleshooting

Problem	Cause	Solution
No laser light	No power supply, or less than 9 V / 12 V (red laser / blue laser).	Check the power supply.
	Laser output power is too low.	Check the Laser output power parameter on the web page.
	Scanner electronics failure.	Contact the technical support.
Scanner is not detected on the network	No power supply, or less than 9 V / 12 V (red laser / blue laser).	Check the power supply.
	Ethernet cable is not connected.	Check the cable.
	Firewall doesn't pass the packages.	Add exceptions or disable the firewall.
	Scanner is already connected in another software.	Drop connections.
	Scanner freezes.	Restart the scanner.
	Scanner electronics failure.	Contact the technical support.
No profile	Incorrect Host IP address.	Make sure that the IP address of the device that receives profiles is 192.168.1.2. See section 11 .
	The object is beyond the working range of the scanner.	Make sure that the object is within the working range of the scanner.
	ROI mode is enabled and the object is beyond the ROI area.	Check ROI settings on the web page.
Obtaining an incorrect profile	Scanner windows are not clean.	Clean the windows with a soft cloth (do not use scratching cleaners or other aggressive media).
	Incorrect scanner settings.	Check general settings on the web page.

17. Warranty policy

Warranty assurance for the Laser Seam Tracking System for Welding Automation RF627Weld Series – 24 months from the date of shipping; warranty shelf-life – 12 months.

18. Technical support

Technical support for issues related to incorrect work of the system is free. When contacting technical support, please provide the serial number and firmware version of the scanner, Riftek Lamia version, and describe the problem in details.

Technical support contacts:

- E-mail: support@riftek.com
- Skype: riftek_support

19. Revisions

Date	Revision	Description
19.08.2019	1.0.0	Starting document.

20. Distributors

AUSTRIA

MBM Industry & Rail Tech GmbH

RAILWAY INSTRUMENTS ONLY

Tullnerbachstraße 36,
 A-3002 Purkersdorf, Austria
 Tel: +43 2231 66000
 Fax: +43 2231 66000 12
office@mbm-industrietechnik.at
www.mbm-tech.at

AUSTRALIA

Applied Measurement Australia Pty Ltd

RAILWAY INSTRUMENTS ONLY

Thornton Plaza, Unit 5,
 27 Thornton Crescent, Mitcham
 VIC 3132, Australia
 Tel: +61 39874 5777
 Fax: +61 39874 5888
sales@appliedmeasurement.com.au
www.appliedmeasurement.com.au

BENELUX

Althen Sensors & Controls BV

Vietweg 17a
 2266KA Leidschendam
 The Netherlands
 Tel: +31 70 3924421
 Fax: +31 70 3644249
sales@althen.nl
www.althensensors.com
www.althencontrols.com

BULGARIA, HUNGARY

RMT Ltd.

R Zahradni 224
 739 21 Paskov, Czech Republic
 Tel: +420 558640211
 Fax: +420 558640218
rmt@rmt.cz
www.rmt.cz

BRAZIL

CAPI Controle

e Automacao Ltda

Rua Itororo, 121, CEP 13466-240
 Americana-SP, Brazil
 Tel: +55 19 36047068
 Fax: +55 19 34681791
capic@capicontrol.com.br
www.capicontrol.com.br

CHILE

Verne SpA

Apoquindo 2818, oficina 31,
 Las Condes, Santiago, Chile
 Tel: +56 2 228858633
info@verne.cl
jsaavedra@verne.cl
www.verne.cl

CHINA

Beijing Gemston Mechanical & Electrical Equipment Co., Ltd

Room 613, Anfu Mansion, Fengtai District, Beijing, China
 Tel: +86 10 6765 0516
 Fax: +86 10 6765 6966
 Mobile: +86 137 1755 1423
dh0526@163.com
www.baoft.cn

CHINA

JRKtech Co., Ltd.

1F, Building 9, 100 Xianlie Rd., Guangzhou, China
 Tel: +86 755 85267190/
 +86 15989362481
 Fax: +86 755 85267190
shengz_k@163.com
www.jrktech.com

CHINA

Micron-Metrology co., ltd

No.2, Kecheng Rd., Industrial Park District, Suzhou, Jiangsu Province, China
 Tel: 0512-65589760/
 +86 189 1806 9807
sales@micron-metrology.cn
www.micron-metrology.cn

CHINA

Zhenshangyou Technologies Co., Ltd.

Rm 2205-2210, Zhongyou Hotel
 1110 Nanshan Road, Nanshan District 518054 Shenzhen, China
 Tel: +86 755-26528100/8011/8012
 Fax: +86 755-26528210/26435640
info@51sensors.com
www.51sensors.com

CZECH REPUBLIC

RMT Ltd.

Zahradni 224
 739 21 Paskov, Czech Republic
 Tel: +420 558640211
 Fax: +420 558640218
rmt@rmt.cz
www.rmt.cz

FINLAND

TERASPYORA-STEELWHEEL OY

RAILWAY INSTRUMENTS ONLY

Juvan teollisuuskatu 28
 FI-02920 ESPOO, Finland
 Tel: +358 400 422 900
 Fax: +358 9 2511 5510
steelwheel@steelwheel.fi
www.teraspyora.fi

FRANCE**BLET Measurement Group S.A.S.**

1 avenue du President Georges
 Pompidou, 92500 Rueil
 Malmaison, France
 Tel: + 33(0)1 80 88 57 85
 Fax: +33(0)1 80 88 57 93
technique@blet-mesure.fr
www.blet-mesure.fr

GERMANY**Hylewicz CNC-Technik SHTRIKH-2 ONLY**

Siemensstrasse 13-15,
 47608 Geldern, Germany
 Tel: +49 2831 91021-20
 Fax: +49 2831 91021-99
info@cnc-step.de
www.cnc-step.de

INDONESIA**PT. DHAYA BASWARA SANIYASA**

Botanic Junction Blok H-9 NO. 7
 Mega Kebon Jeruk, Joglo
 Jakarta 11640, Indonesia
 Tel: + 62 21 29325859
management@ptdbbs.co.id

ITALY**FAE s.r.l.**

Via Tertulliano, 41
 20137 Milano, Italy
 Tel: +39-02-55187133
 Fax: +39-02-55187399
fae@fae.it
www.fae.it

MALAYSIA**OptoCom InstruVentures**

H-49-2, Jalan 5, Cosmoplex
 Industrial Park, Bandar Baru
 Salak Tinggi, Sepang, Malaysia
 Tel: 603 8706 6806
 Fax: 603 8706 6809
optocom@tm.net.my
www.optocom.com.my

GERMANY**Disynet GmbH**

Breyeller Str. 2
 41379, Brueggen
 Tel: +49 2157 8799-0
 Fax: +49 2157 8799-22
disynet@sensoren.de
www.sensoren.de

INDIA**Pragathi Solutions**

#698, 5th Main, 8th Cross,
 HAL 3rd Stage,
 New Tippasandra Road,
 Bangalore, 560075, India
 Tel: +91 80 32973388
 Tel/fax: +91 80 25293985
 Mobile: +91 9448030426/
 +919448492380
sales@pragathisolutions.in
arghya@pragathisolutions.in
www.pragathisolutions.in

IRAN**Novin Industrial Development Grp.**

Tel: +98 21 44022093-6
 Fax: +98 21 43858794
 Mobile: +98 9123207518
info@novinid.com
www.novinid.com

JAPAN**Tokyo Instruments, Inc.**

6-18-14 Nishikasai, Edogawa-ku,
 Tokyo, 134-0088 Japan
 Tel: +81 3 3686 4711
 Fax: +81 3 3686 0831
f_kuribayashi@tokyoinst.co.jp
www.tokyoinst.co.jp

NORWAY**Salitec AS**

PB 468,
 N-1327 Lysaker
 Tel: +47 23 891015
 Fax: +47 92101005
mail@salitec.no
www.salitec.no

GERMANY**Finger GmbH & Co. KG**

OPTICAL MICROMETERS ONLY
 Sapelloh 172,
 31606 Warmssen, Germany
 Tel: +49 5767 96020
 Fax: +49 5767 93004
finger@finger-kg.de
www.finger-kg.de

INDIA**Paragon Instrumentation Engineers Pvt. Ltd.**

RAILWAY INSTRUMENTS ONLY
 200, Station Road,
 Roorkee, 247 667, India
 Tel: +91-1332-272394
tanuj@paragoninstruments.com
www.paragoninstruments.com

ISRAEL**Nisso Dekalo Import Export LTD**

1 David Hamelech Street
 Herzlia 46661 Israel
 Tel: +972-99577888
 Fax: +972-99568860
eli@fly-supply.net
www.fly-supply.net
www.aircraft-partsupply.com

LATVIA, ESTONIA**SIA "SOLARTEX"**

RAILWAY INSTRUMENTS ONLY
 Dunties 15a, 5th floor, office B7
 Riga, Latvia
 Tel.: +371 67 130 787
solartex@inbox.lv

PERU**Verne Peru S.A.C.**

Las Codornices 104,
 Surquillo, Lima, Peru
 Tel/fax: +51 992436734
info@verne.cl
www.verne.cl

POLAND

MTL ASCO Sp. z o.o.
RAILWAY INSTRUMENTS ONLY
 ul. Wielowiejska 53 44-120
 PYSKOWICE (k/ GLIWIC),
 Poland
 Tel: + 48 32 230 45 70
 Fax: + 48 32 332 70 14
rail@ascorail.eu
www.ascorail.eu

RUSSIA

Diesel-test-Komplekt LLC
 620030, Karjernaya St, 16
 Ekaterinburg, Russia
 Tel/fax: +7 343 2227565
 Tel/fax: +7 343 2227370
mail@d-test.ru
www.d-test.ru

SOUTH KOREA

PROSEN. CO., LTD
 M-1001, Songdo techno park IT
 center, 32, Songdogwahak-ro,
 Yeonsu-gu, Incheon, 21984,
 Republic of Korea
 Tel: +82-32-811-3457
 Fax: +82-32-232-7458
trade@prosen.co.kr
www.prosen.co.kr

SWITZERLAND

ID&T GmbH
 Gewerbestrasse 12/a
 8132 Egg (Zurich), Switzerland
 Tel: + 41 44 994 92 32
 Fax: + 41 44 994 92 34
info@idtlaser.com
www.idtlaser.com

TAIWAN

Nano-Trend Technology Co., Ltd.
 No.365-6, Zhongshan Rd., Sanxia
 Dist., New Taipei City 23741,
 Taiwan (R.O.C.)
 Tel: +886-2-8671-9560
 Fax: +886-2-8671-0084
nt@nano-trend.com
www.nano-trend.com

PORTUGAL

**Campal Inovacoes
 Ferroviarias Lda.**
RAILWAY INSTRUMENTS ONLY
 Lagoas Park, Edificio 7, 1° Piso
 Sul 2740-244 Porto Salvo, Oeiras,
 Portugal
 Tel: +351 21 584 4348
campal@campal.pt
www.campal.pt

SERBIA, SLOVAKIA

RMT Ltd.
 Zahradni 224
 739 21 Paskov, Czech Republic
 Tel: +420 558640211
 Fax: +420 558640218
rmt@rmt.cz
www.rmt.cz

SOUTH KOREA

BS Holdings
 B-201, Wonpogongwon 1ro,
 59 Danwon-gu, Ansan-si,
 Gyeonggi-do, 15455,
 Republic of Korea
 Tel: +82-31-411-5011
 Fax: +82-31-411-5015
bsh5011@hanmail.net
www.lasersolution.co.kr

SWEDEN, DENMARK

BLConsult
 Ryssbalt 294,
 95 291 KALIX, Sweden
 Mobile: +46 70 663 19 25
info@blconsult.se
www.blconsult.se

THAILAND

Advantech Solution Co., Ltd.
 20/170 Motorway Rd.,
 Kwang Pravet, Khet Pravet,
 Bangkok, Thailand 10250
 Tel: +662-1848705
 Fax: +662-1848708
sales@advantechsoluton.com
www.advantechsoluton.com

RUSSIA

Sensorika-M LLC
 Dmitrovskoye shosse 64-4
 127474, Moscow, Russia
 Tel: +7 499 487 0363
 Fax: +7 499 487 7460
info@sensorika.com
www.sensorika.com

SOUTH AFRICA

Ratcom Enterprise Pty Ltd
 CSIR BUILDING 35, Office 78
 Meiring Naude Road, Brummeria
 Pretoria, 0084 South Africa
 Tel: + 27 12 841 2032
 Fax: + 27 86 225 0650
info@ratcom.co.za
www.ratcom.co.za

SPAIN

Iberfluid Instruments S.A.
 C/ Botanica, 122
 08908 L'Hospitalet de Llobregat,
 Barcelona
 Tel: +34 93 447 10 65
 Fax: +34 93 334 05 24
myct@iberfluid.com
www.iberfluid.com

SWEDEN, DENMARK

Latronix AB
 Propellervagen 10,
 183 62 Taby, Sweden
 Tel.: +46 08-446 48 30
 Fax: +46 08-446 48 39
sales@latronix.se
www.latronix.se

TURKEY

TEKMA Muhendislik A.S.
 Cevizli Mh. M. Kemal Cd.,
 Hukukcular Towers,
 A-Blok, No: 66-A/39
 Kartal – Istanbul
 Tel: +90 216 970 1318
 Tel: +90 850 840 2334
info@tekma.eu
www.tekma.eu

UKRAINE

KODA

Frunze st 22
61002, Harkov, Ukraine
Tel/fax: +38 057 714 26 54
mail@koda.com.ua
www.koda.com.ua

UNITED KINGDOM, IRELAND

Ixthus Instrumentation Ltd

The Stables, Williams' Barns
Tiffield road, Towcester, Northants
Tel: +44 1327 353437
Fax: +44 1327 353564
info@ixthus.co.uk
www.ixthus.co.uk

USA, CANADA, MEXICO

International Electronic Machines Corporation

RAILWAY INSTRUMENTS ONLY

850 River Street, Troy,
New York, USA
Tel: +1 518 268-1636
Fax: +1 518 268-1639
marketing@iem.net
www.iem.net

USA, CANADA, MEXICO

Acuity Products of Schmitt Industries, Inc.

2765 NW Nicolai Street
Portland, OR, 97210, USA
Tel: +1 503 227 7908
Fax: +1 503 223 1258
sales@acuitylaser.com
www.acuitylaser.com