



RIFTEK
Sensors & Instruments



SPACERS THICKNESS MEASUREMENT SYSTEM

RF035 Series

User's manual

www.riftek.com
info@riftek.com

Certified according to ISO 9001:2015



Contents

1.	Safety precautions.....	3
2.	CE compliance.....	3
3.	Laser safety.....	3
4.	General information.....	3
5.	Basic technical data.....	4
6.	Example of item designation when ordering.....	4
7.	Structure and operating principle.....	5
8.	Connection	6
9.	Network setting.....	6
10.	Service program.....	6
10.1.	System requirements.....	6
10.2.	Main window	6
10.3.	Setting parameters.....	7
10.4.	Measurement procedure.....	7
10.5.	Log.....	7
11.	Technical support.....	7
12.	Warranty policy.....	8
13.	Revisions.....	8
14.	Distributors	8

1. Safety precautions

- Use supply voltage and interfaces indicated in the system specifications.
- In connection/disconnection of cables, the system power must be switched off.
- Do not use the system in locations close to powerful light sources.
- To obtain stable results, wait about 20 minutes after sensor activation to achieve uniform sensor warm-up.


2. CE compliance

The system has been developed for use in industry and meets the requirements of the following Directives:

- EU directive 2014/30/EU. Electromagnetic compatibility (EMC).
- EU directive 2011/65/EU, "RoHS" category 9.

3. Laser safety

The system contains laser sensors that belong to Class 2 according to IEC/EN 60825-1:2014. Maximum output power is 1 mW. The following warning label is placed on the sensor body:



The following safety measures should be taken while operating the sensor:

- Do not target laser beam to humans.
- Do not disassemble the sensor.
- Avoid staring into the laser beam.

4. General information

The system is designed for non-contact laser scanning and measurement of spacers thickness.

Field of application: large-scale production.

5. Basic technical data

Parameter	Value	
Thickness measurement range, mm	from 0.6 to 3.5	
Measurement accuracy, μm	± 5	
Spacers diameter, mm	25.4	
Productivity, pcs/hour	>1000	
Light source	red semiconductor laser, 660 nm wavelength	
Output power, mW	<1	
Laser safety class	2 (IEC60825-1)	
Interface	Ethernet	
Power supply, V	220	
Environmental resistance	Vibration	20 g / 10...1000 Hz, 6 hours for each of XYZ axes
	Shock	30 g / 6 ms
	Permissible ambient light, lx	30000
	Relative humidity, %	5-95 (no condensation)
	Operating ambient temperature, °C	0...+45
	Storage temperature, °C	-20...+70
Dimensions, mm	442x240x339	
Housing material	aluminum	

Note: System parameters can be changed for a specific task.

6. Example of item designation when ordering

RF035-Tmin/Tmax-D


Symbol	Description
Tmin/Tmax	Minimum/maximum spacers thickness, mm
D	Spacers diameter, mm

Example: RF035-0.6/3.5-25.4 – Spacers Thickness Measurement System RF035 Series, thickness measurement range - from 0.6 to 3.5 mm, spacers diameter - 25.4 mm.


7. Structure and operating principle

Operation of the system is based on the principle of laser scanning of the spacer surface by two laser sensors located on the opposite sides of the spacer.

The structure of the system is shown below (the side covers are removed):



The system contains a base, on which the following parts are installed: a tray for spacers (1), dispenser (2) with a drive (3), disc (4) with a drive (5), rotation drive for spacers (6), tray for defective spacers (7), tray for good spacers (8), containers (9) and (10) for collecting the defective and good spacers respectively, laser sensors (11) and (12).



Disc (4) carries two calibration spacers (13) of the known thickness. On the side panel, there is a connector for power supply and a turn-on button (14 and 15), and a connector for connection to PC.

The system operates as follows.

Controlled spacers are manually placed on the tray (1), the dispenser (2) successively throws the spacers onto the rotating disk (4), which moves the spacers in the measuring zone of laser sensors (11) and (12). When the spacer is in the measuring zone, it is rotated by the drive (6), and, as a result, the thickness is measured in a spiral on the spacer surface, which allows to register the extended surface defects. After the measurement, the spacer comes into the tray (7), which tilts and throws it into the container for defective spacers (9), or into the container for good spacers (10).

8. Connection

- Connect the power cable to 220V.
- Connect the Ethernet cable to PC.

9. Network setting

6

The system is shipped with the following default network configuration:

- IP address: 192.168.0.3.

It is imperative to configure the network card of the PC in the following address space: 192.168.0.X.

10. Service program


To run the service program, you need to double-click on the executable file - **RF035.exe**.

10.1. System requirements

- Operating system Windows 7 and later.

10.2. Main window

After you run the service program, the main window appears:



10.3. Setting parameters

Before you start, you need to set (check) the following parameters:


- **Thickness, microns** (nominal thickness value).
- **Tolerance, microns**.
- Sorting method:
 - **Average measure** (average thickness value).
 - **Min Max measure** (minimum and maximum thickness values).

10.4. Measurement procedure

7

After you set/check all parameters, the system is ready to use.

To start the measurement process, click **Start**. Measurement and sorting of the spacers are performed automatically.



The number of good spacers (**OK**) and the number of defective spacers (**NOK**) are displayed in the upper right corner of the window.

A graphical representation of the thickness profile of the last measured spacer is shown in the central part of the window.

In the upper left part of the window, you can see the thickness value of the calibration spacer (**Calibr**), average thickness value (**Avr**), minimum thickness value (**Min**), maximum thickness value (**Max**), and the difference between the minimum and maximum values (**Max Min**). All values are given for the last measured spacer.

10.5. Log

Measurement results are written to the file (**measures.csv**), which is located in the directory with the service program.

11. Technical support

Technical assistance related to incorrect work of the system and to problems with a service program is free.

Requests for technical assistance should be addressed to support@riftek.com.

12. Warranty policy

Warranty assurance for the Spacers Thickness Measurement System RF035 Series - 24 months from the date of putting in operation; warranty shelf-life - 12 months.

13. Revisions

Date	Revision	Description
19.06.2018	1.0.0	Starting document.

14. Distributors

AUSTRALIA

Applied Measurement Australia Pty Ltd
RAILWAY INSTRUMENTS ONLY
Thornton Plaza, Unit 5,
27 Thornton Crescent, Mitcham
VIC 3132, Australia
Tel: +61 39874 5777
Fax: +61 39874 5888
sales@appliedmeasurement.com.au
www.appliedmeasurement.com.au

BELGIUM

Althen Sensors & Controls BV
Verrijn Stuartlaan 40, 2288 EL,
Rijswijk, Leidschendam
The Netherlands
Tel: +31 0 70 392 4421
Tel: +31 0 61 396 7830
Tel: +31 0 64 323 8393
sales@althen.nl
info@althen.nl
www.althensensors.com

BOSNIA AND HERZEGOVINA

ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: +48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

8

BRAZIL

CAPI Controle e Automação Ltda
Rua Itororó, 121, CEP 13466-240
Americana-SP, Brazil
Tel: +55 19 36047068
Fax: +55 19 34681791
capi@capicontrole.com.br
www.capicontrole.com.br

BULGARIA

ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
ul. Wielowiejska 53, 44-120
Pyskowice, Poland
Tel: +48 32 230 45 70
Fax: +48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

CHILE

MOL INGENIERIA LTDA
EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
República de Honduras 11936
Las Condes, Santiago de Chile
Tel: +56 9 59200362
hconcha@molingeneria.com
www.molingeneria.com

CHILE

Verne SpA
Apoquindo 2818, oficina 31
Las Condes, Santiago, Chile
Tel: +56 2 228858633
info@verne.cl
saavedra@verne.cl
www.verne.cl

CHINA

Beijing Haiwei Lutong Technology Co., Ltd
Yard 1, Tianxing Street, Fangshan District, Beijing, China
Tel: +86 10 8366 1866
Fax: +86 10 8366 1866
info@haiwl.com
www.haiwl.com

CHINA

Chongqing Wolf Industrial Technology Co., Ltd
Room 2307 / 2308, Light of City international business building,
No. 19 Jiangnan Avenue, Nan'an District, Chongqing, China
Tel: 023 62832618
Fax: 023 62832113
info@wolf-hk.com
www.wolf-hk.com

CHINA

Beijing Gemston Mechanical & Electrical Equipment Co., Ltd

RAILWAY INSTRUMENTS ONLY
 Room 613, Anfu Mansion, Fengtai District, Beijing, China
 Tel: +86 10 6765 0516
 Fax: +86 10 6765 6966
 Mobile: +86 137 1755 1423
dh0526@163.com
www.baoft.cn

CHINA

Xi'an Win-Success Automation Technology Co.,Ltd

Room 3-1-1039, Iduhui Building, No.11 Tangyan South Road High-Tech Zone, Xi'an Shaanxi PRC, China
 Tel: +86 29 81106280
 Fax: +86 29 81106285
 Mob: +86 133 19271405
info@maxsenor.com
www.maxsensor.com

CHINA

Micron-Metrology co., Ltd

No.2, Kecheng Rd., Industrial Park District, Suzhou, Jiangsu Province., China
 Tel: 0512 65589760
 Mob: +86 189 1806 9807
sales@micron-metrology.cn
www.micron-metrology.cn

CHINA

Zhenshangyou Technologies Co., Ltd

Rm 2205-2210, Zhongyou Hotel 1110 Nanshan Road, Nanshan District 518054 Shenzhen, China
 Tel: +86 755-26528100/8011/8012
 Fax: +86 755-26528210/26435640
info@51sensors.com
www.51sensors.com

CROATIA

ASCO RAIL sp. z o.o.

EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
 ul. Wielowiejska 53, 44-120 Pyskowice, Poland
 Tel: +48 32 230 45 70
 Fax: +48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

CZECH REPUBLIC

ASCO RAIL sp. z o.o.

EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
 ul. Wielowiejska 53, 44-120 Pyskowice, Poland
 Tel: +48 32 230 45 70
 Fax: +48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

DENMARK

BLConsult

Ryssbält 294
 95 291 Kalix, Sweden
 Tel: +46 70 663 19 25
info@blconsult.se
www.blconsult.se

ESTONIA

FoodLab OÜ

Haabersti linnaosa, Astangu tn 52 13519 Eesti, Tallinn, Estonia
 Tel: +372 56 363110
foodlab.ee@gmail.com

FINLAND

Kvalitest Industrial AB

EXCEPT FOR RAILWAY INSTRUMENTS
 Ekbacksvägen 28,
 16869 Bromma, Sweden
 Tel: +46 0 76 525 5000
sales@kvalitest.com
www.kvalitest.com
www.kvalitest.se

FINLAND

TERÄSPYÖRÄ-STEELWHEEL OY

RAILWAY INSTRUMENTS ONLY
 Juvan teollisuuskatu 28
 FI-02920 ESPOO, Finland
 Tel: +358 400 422 900
 Fax: +358 9 2511 5510
steelwheel@steelwheel.fi
www.teraspyora.fi

FRANCE

BLET Measurement Group S.A.S.

1 avenue du Président Georges Pompidou, 92500 Rueil Malmaison, France
 Tel: +33 0 1 80 88 57 85
 Fax: +33 0 1 80 88 57 93
technique@blet-mesure.fr
www.blet-mesure.fr

GERMANY

Disynet GmbH

Breyeller Str. 2, 41379 Brueggen, Germany
 Tel: +49 2157 8799 0
 Fax: +49 2157 8799 22
disynet@sensoren.de
www.sensoren.de

GERMANY

**Finger GmbH & Co. KG
 OPTICAL MICROMETERS ONLY**

Sapelloh 172, 31606
 Warmen, Germany
 Tel: +49 5767 96020
 Fax: +49 5767 93004
finger@finger-kg.de
www.finger-kg.de

GERMANY

ALTHEN GmbH Meß- und Sensortechnik

Dieselstrasse 2, 65779 Kelkheim, Germany
 Tel: +49 0 6195 7 00 60
info@althen.de
www.althensesors.com/de/

HUNGARY

ASCO RAIL sp. z o.o.

EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
 ul. Wielowiejska 53, 44-120 Pyskowice, Poland
 Tel: +48 32 230 45 70
 Fax: +48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

INDIA

Influx Big Data Solutions Pvt Ltd
 No.2, Krishvi, Ground Floor,
 Old Airport Road, Domlur,
 Bangalore - 560071, India
 Tel: +91 73 37748490
 Tel: +91 94 48492380
milan@influxtechnology.com
support_india@influxtechnology.com
www.influxtechnology.com

INDIA

Paragon Instrumentation Engineers Pvt. Ltd.
RAILWAY INSTRUMENTS ONLY
 200, Station Road,
 Roorkee, 247 667, India
 Tel: +91 1332 272394
tanuj@paragoninstruments.com
www.paragoninstruments.com

INDONESIA

PT. DHAYA BASWARA SANIYASA
 Botanic Junction Blok H-9 NO. 7
 Mega Kebon Jeruk, Joglo
 Jakarta, 11640, Indonesia
 Tel: +62 21 2932 5859
management@ptdbs.co.id

ISRAEL

Nisso Dekalo Import Export LTD
 1 David Hamelech Street
 Herzlia 46661 Israel
 Tel: +972 99577888
 Fax: +972 99568860
nissodekaloltd@outlook.com
www.fly-supply.net
www.aircraft-partsupply.com

ITALY

FAE s.r.l.
 Via Tertulliano, 41
 20137 Milano, Italy
 Tel: +39 02 55187133
 Fax: +39 02 55187399
fao@fae.it
www.fae.it

JAPAN

Tokyo Instruments, Inc.
 6-18-14 Nishikasai, Edogawa-ku,
 Tokyo, 134-0088 Japan
 Tel: +81 3 3686 4711
 Fax: +81 3 3686 0831
f_kurabayashi@tokyoinst.co.jp
www.tokyoinst.co.jp

10

LATVIA

FoodLab OÜ
 Haabersti linnaosa, Astangu tn 52
 13519 Eesti, Tallinn, Estonia
 Tel: +372 56363110
foodlab.ee@gmail.com

LUXEMBOURG

Althen Sensors & Controls BV
 Verrijn Stuartlaan 40, 2288 EL,
 Rijswijk, Leidschendam
 The Netherlands
 Tel: +31 0 70 392 4421
 Tel: +31 0 61 396 7830
 Tel: +31 0 64 323 8393
sales@althen.nl
info@althen.nl
www.althensensors.com

MALAYSIA

OptoCom InstruVentures
 H-49-2, Jalan 5, Cosmoplex
 Industrial Park, Bandar Baru
 Salak Tinggi, Sepang, Malaysia
 Tel: 603 8706 6806
 Fax: 603 8706 6809
optocom@tm.net.my
www.optocom.com.my

MONTENEGRO

ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
 ul. Wielowiejska 53, 44-120
 Pyskowice, Poland
 Tel: +48 32 230 45 70
 Fax: +48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

NETHERLANDS

Althen Sensors & Controls BV
 Verrijn Stuartlaan 40, 2288 EL,
 Rijswijk, Leidschendam
 The Netherlands
 Tel: +31 0 70 392 4421
 Tel: +31 0 61 396 7830
 Tel: +31 0 64 323 8393
sales@althen.nl
info@althen.nl
www.althensensors.com

NORWAY

BLConsult
 Ryssbält 294,
 95 291 Kalix, Sweden
 Tel: +46 70 663 19 25
info@blconsult.se
www.blconsult.se

NORWAY

Salitec AS
 PB 468, N-1327
 Lysaker, Norway
 Tel: +47 23 891015
 Fax: +47 92101005
mail@salitec.no
www.salitec.no

PERU

Verne Perú S.A.C.
 Las Codornices 104,
 Surquillo, Lima, Peru
 Tel/fax: +51 992436734
info@verne.cl
www.verne.cl

POLAND

ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
 ul. Wielowiejska 53, 44-120
 Pyskowice, Poland
 Tel: +48 32 230 45 70
 Fax: +48 32 233 21 34
biuro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

POLAND

RIFTEK EUROPE sp. z o.o.
 ul. Domaniewska 17/19, 02-672
 Warsaw, Poland
info@riftek.com
www.riftek.com

PORTUGAL

Campal Inovacoes Ferroviarias Lda.
 Lagoas Park, Edifício 7, 1º Piso Sul, 2740-244 Porto Salvo, Oeiras, Portugal
 Tel: +351 21 584 4348
campal@campal.pt
www.campal.pt

SERBIA

ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
 ul. Wielowiejska 53, 44-120
 Pyskowice, Poland
 Tel: +48 32 230 45 70
 Fax: + 48 32 233 21 34
buro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

SLOVAKIA

ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
 ul. Wielowiejska 53, 44-120
 Pyskowice, Poland
 Tel: +48 32 230 45 70
 Fax: + 48 32 233 21 34
buro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

SOUTH KOREA

PROSEN. CO., LTD
 M-1001, Songdo techno park IT center, 32, Songdogwahak-ro, Yeonsu-gu, Incheon, 21984, Republic of Korea
 Tel: +82 32 811 3457
 Fax: +82 32 232 7458
trade@prosen.co.kr
www.prosen.co.kr

SLOVENIA

ASCO RAIL sp. z o.o.
EXCLUSIVE REPRESENTATIVE FOR RAILWAY EQUIPMENT
 ul. Wielowiejska 53, 44-120
 Pyskowice, Poland
 Tel: +48 32 230 45 70
 Fax: + 48 32 233 21 34
buro@ascorail.pl
export@ascorail.pl
www.ascorail.pl

SOUTH KOREA

BS Holdings
 B-201,Wonpogongwon 1ro, 59 Danwon-gu, Ansan-si, Gyeonggi-do 15455, Republic of Korea
 Tel: +82 31 411 5011
 Fax: +82 31 411 5015
bsh5011@hanmail.net
www.lasersolution.co.kr

SPAIN

IBERFLUID Instruments S.A.
 C/ Botanica, 122, 08908 L'Hospitalet de Llobregat Barcelona
 Tel: +34 93 447 10 65
 Fax: +34 93 334 05 24
myct@iberfluid.com
www.iberfluid.com

SWEDEN

BLConsult
 Ryssbält 294, 95 291 Kalix, Sweden
 Tel: +46 70 663 19 25
info@blconsult.se
www.blconsult.se

SWEDEN

Kvalitest Industrial AB
EXCEPT FOR RAILWAY INSTRUMENTS
 Ekbacksvägen 28, 16869 Bromma, Sweden
 Tel: +46 0 76 525 5000
sales@kvalitest.com
www.kvalitest.com
www.kvalitest.se

SWITZERLAND

ID&T GmbH
 Gewerbestrasse 12/a 8132 Egg (Zurich), Switzerland
 Tel: + 41 44 994 92 32
 Fax: + 41 44 994 92 34
info@idtlaser.com
www.idtlaser.com

THAILAND

Advantech Solution Co., Ltd.
 20/170 Motorway Rd., Kwang Pravet, Khet Pravet, Bangkok, Thailand 10250
 Tel: +662 1848705
 Fax: +662 1848708
sales@advantechsolution.com
www.advantechsolution.com

TURKEY

MAK Elektronik Malzeme Analiz ve Kalite Kontrol Cihazlari Dis Tic. Ltd. Sti.
 Cenap Sahabettin Sokak, No:39, 34718 Kosuyolu - Kadikoy / Istanbul - TURKEY
 Tel: +90 216 402 10 34
 Fax: +90 216 402 10 35
ulastac@metalografi.net
www.makelektronik.com.tr

TURKEY

TEKMA Mühendislik A.S.
 Cevizli Mh. M. Kemal Cd., Hukukçular Towers, A-Blok, No: 66-A/39 Kartal - İstanbul
 Tel: +90 216 970 1318
 Tel: +90 850 840 2334
info@tekma.eu
www.tekma.eu

UKRAINE

KODA
 Frunze st. 22, 61002, Harkov, Ukraine
 Tel/Fax: +38 057 714 26 54
mail@koda.com.ua
www.koda.com.ua

**UNITED KINGDOM,
IRELAND****Althen UK**

Northamptonshire
United Kingdom
Tel: +44 0 7823 921427
t.stoyles@althen.co.uk
www.althensensors.com
www.althencontrols.com

USA**Althen Sensors & Controls**

2531 Bradley St., Oceanside, CA,
92056, USA
Tel: 858 633 3572
r.ream@althensensors.com

USA, CANADA, MEXICO**Acuity Products of Schmitt
Industries, Inc.**

2765 NW Nicolai Street
Portland, OR, 97210, USA
Tel: +1 503 227 7908
Fax: +1 503 223 1258
sales@acuitylaser.com
www.acuitylaser.com

USA, CANADA, MEXICO**International Electronic
Machines Corporation****RAILWAY INSTRUMENTS ONLY**

850 River Street, Troy,
New York, USA
Tel: +1 518 268-1636
Fax: +1 518 268-1639
marketing@iem.net
www.iem.net